






















P1			16 PCS
P2			16 PCS
P3		M4X35mm	2 PCS
P4		M8x30mm	20 PCS
P5		M3.5x12mm	2 PCS
P6			4 PCS
P7		M5x40mm	8 PCS
P8			1 PC
P9		M6x50mm	8 PCS
P10			8 PCS
P11			4 PCS
P12			2 PCS
P13			12 PCS
P14			2 PCS
P15			4 PCS
P16			2 PCS
P17		M5.8x50mm	4 PCS
P18		M4x12mm	36 PCS
P19		M5.8x30mm	4 PCS


1




2




3




4




5




6






7




8




9




10




How to Adjust Door Hinges



Adjust door up and down




Adjust door forward and back



Adjust door left and right

11



12

